



Installation of RIONET SELECTOR


1. Choose HU-07S (Stand alone version) or HU-07 (Noah version)



2. Click Disk 1



3. Choose "Setup.exe" file



4. Follow instruction on the screen

